CORRECTION

There are some mistakes in the instruction book, so correct as below.

Page	INCORRECT	CORRECT
P.14 Step ⑧- ④	The current setting for this option, 36, should be changed if there is interference. Select a channel that is far from 36.	The current setting for this option, 38, should be changed if there is interference. Select a channel that is far from 38.
P. 58 Connection	Preset CH36	Preset CH38

DBR-T200GB<BRX1029-A>